
Tel: 415.333.6428 Tel: 888.764.2453 Fax: 415.333.2032 E: info@bikeparking.com Palmer Group, LLC: 1728 Ocean Avenue #132 San Francisco CA 94112 USA



Specifications

- ◆ Three mounting holes ideally accept 1/2 inch fasteners
- Recommended rack spacing; 16 inch min.w/ vertical stagger
- Vertical stagger should be 10 inches
- Ground to top of rack should be 72 inches for first rack
- Ground to top of second rack should be 82 inches
- Allow 14" before your first rack and 16" beyond your last rack
- Use proper expansion bolts or Rawl Spikes for concrete wall
- ◆ Common stud walls should have 5/8" plywood backing added

- If plywood backing is used then use machine bolts for top bolt
- ◆ Drill 1/2" holes for machine bolts first
- Place machine bolts through backside of plywood before mounting
- Hang racks on protruding top bolt shafts and apply nuts
- Align racks vertically by using level
- Use lag bolts for the middle and bottom fasteners
- Apply epoxy to top bolt shaft threads to make removal difficult
- Discourage use of cable locks since they are easily cut